

Part #	DESCRIPTION	MODEL(S)
EQ7347	FUEL INJ HOSE -KIT	I0240A
EQ7354	FUEL INJ HOSE -KIT	I0240B
EQ7345	FUEL INJ HOSE -KIT	I0240B3B,9B,4BK,8B
EQ7346	FUEL INJ HOSE -KIT	I0240B7B
EQ7353	FUEL INJ HOSE -KIT	I0360ES
EQ7308	FUEL INJ HOSE -KIT	I0360KB,A,AB,C,CB,G,GB,H,HB,J,JB,D,DB
EQ7303	FUEL INJ HOSE -KIT	I0470D,U,V
EQ7301	FUEL INJ HOSE -KIT	I0470E
EQ7295	FUEL INJ HOSE -KIT	I0470F19B,26B,26C,26D,3B,7B,19K,27B,29B,31B,32B,33B,34B,36B,18B,30B,4B,1B,28B
EQ7294	FUEL INJ HOSE -KIT	I0470J,H,C,K,N; 0470G7B,7F,10B,GCI
EQ7307	FUEL INJ HOSE -KIT	I0470K14B
EQ7306	FUEL INJ HOSE -KIT	I0470L22B
EQ7305	FUEL INJ HOSE -KIT	I0470L25B,26B,9B,8B,11B,15B,19B,20B,21B,24B,27B,12B,23B,28B,29B,5B
EQ7304	FUEL INJ HOSE -KIT	I0470M
EQ7343	FUEL INJ HOSE -KIT	I0470N10B,11B,12B,13B,16B,17B,19B,20B
EQ7344	FUEL INJ HOSE -KIT	I0470S
EQ7326	FUEL INJ HOSE -KIT	I0520BB,BA,B
EQ7324	FUEL INJ HOSE -KIT	I0520CB
EQ7325	FUEL INJ HOSE -KIT	I0520CB9B,9F,9W,12B,14B,13B,20B,21B,28B,29B,33B,36B
EQ7291	FUEL INJ HOSE -KIT	I0520D113B,121B,26B,32B,166B,173B,185B,136B,129B,153B,160B,53B,67B,81B,48B,62B,72B,114B,122B,35B,41B,130B,137B,54B,68B,82B
EQ7302	FUEL INJ HOSE -KIT	I0520D15B
EQ7293	FUEL INJ HOSE -KIT	I0520D169B,11B,D10B,178B,182B
EQ7323	FUEL INJ HOSE -KIT	I0520E
EQ7322	FUEL INJ HOSE -KIT	I0550A
EQ7321	FUEL INJ HOSE -KIT	I0550B
EQ7320	FUEL INJ HOSE -KIT	I0550C
EQ7292	FUEL INJ HOSE -KIT	I0550D; I0520D110B,118B,89B,95B,101B,107B,111B,119B,115B,123B,84B,90B,96B,102B,108B,116B,124B,29B,30B,33B,34B,39B,40B,175B,176B,184B,186B,138B,131B,139B,142B,145B,148B,127B,134B,141B,144B,147B,126B,138B,55B,69B,83B,56B,70B,51B,65B,79B,50B,64B,78B,110B,118B,30U,40K,172B,133B,85B,86B,92B,98B,91B,97B,103B,109B,117B,88B,94B,100B,106B,112B,120B,24M,47B,22B,23B,24B,27B,31B,167B,174B,155B,128B,135B,125B,132B,140B,143B,146B,149B,162B,156B,150B,157B,163B,154B,161B,52B,66B,80B,43B,57B,71B,58B,72B,44B,45B,59B,73B,49B,63B,77B,46B,49B,74B,61B,75B,63B,23M,60B,22C,24K,24N,171B,174B,177B,151B,158B,164B,152B,159B,165B,154B,87B,98B,99B,105B,170B
EQ7319	FUEL INJ HOSE -KIT	I0550D2B,3B,7B,8B



Teledyne Continental Motors, Inc.
A Teledyne Technologies Company

Part #	DESCRIPTION	MODEL(S)
EQ7352	FUEL INJ HOSE -KIT	I0550E
EQ7318	FUEL INJ HOSE -KIT	I0550F5B,6B,7B,8B,9B,10B,11B,12B,13B,14B,18B,19B,20B,21B,24B; I0550L11B,12B,13B,17B; L/I0520P,K,J,F,L,A
EQ7315	FUEL INJ HOSE -KIT	I0550G
EQ7316	FUEL INJ HOSE -KIT	I0550G5B, 6B
EQ7317	FUEL INJ HOSE -KIT	I0550L; I0550F
EQ7312	FUEL INJ HOSE -KIT	TSI0360MB
EQ7314	FUEL INJ HOSE -KIT	LTSI0360RB
EQ7311	FUEL INJ HOSE -KIT	TSI0360RB
EQ7310	FUEL INJ HOSE -KIT	TSI0360SB
EQ7313	FUEL INJ HOSE -KIT	LTSI0520AE
EQ7340	FUEL INJ HOSE -KIT	TSI0520AE
EQ7341	FUEL INJ HOSE -KIT	TSI0520AE3B,5B,7B
EQ7339	FUEL INJ HOSE -KIT	TSI0520BE,TSI0550A, C
EQ7338	FUEL INJ HOSE -KIT	TSI0520CE
EQ7337	FUEL INJ HOSE -KIT	TSI0520D, DB
EQ7336	FUEL INJ HOSE -KIT	TSI0520EB,E,BB,B
EQ7335	FUEL INJ HOSE -KIT	TSI0520H,C,G
EQ7334	FUEL INJ HOSE -KIT	TSI0520J10B,12B,9B; TSI0520KB4B,3B; TSI0520JB9B,10B,12B
EQ7331	FUEL INJ HOSE -KIT	TSI0520M,P,R,AF1B
EQ7333	FUEL INJ HOSE -KIT	TSI0520NB9B,5B,10B,12B,13B,22B,25B,26B,27B,28B,33B,14B, 16B,29B,30B; TSI0520N9B,10B,12B,14B,16B
EQ7332	FUEL INJ HOSE -KIT	TSI0520R7B, 12B; TSI0520AF2B, 3B
EQ7330	FUEL INJ HOSE -KIT	TSI0520T
EQ7328	FUEL INJ HOSE -KIT	TSI0520UB
EQ7329	FUEL INJ HOSE -KIT	TSI0520UB4B,11B,13B,14B,16B,17B,5B,5F,10B, 12B
EQ7327	FUEL INJ HOSE -KIT	TSI0520VB
EQ7342	FUEL INJ HOSE -KIT	TSI0550B
EQ7348	FUEL INJ HOSE -KIT	TSI0L550B
EQ7349	FUEL INJ HOSE -KIT	TSI0L550C